

Quick Start

For CIS ToF Camera Sensor - Prototype May 2019

System Configurations

- Ubuntu 16.04
 - ROS Kinetic
- Ubuntu 18.04
 - ROS Melodic
- USB 3.0 Port
- CIS ToF Camera Sensor
 - Prototype of May 2019

Installation

Installing ROS

Install "ROS Desktop Full" on Ubuntu PC.

- ROS Kinetic for Ubuntu 16.04
 - <http://wiki.ros.org/kinetic/Installation/Ubuntu>
- ROS Melodic for Ubuntu 18.04
 - <http://wiki.ros.org/melodic/Installation/Ubuntu>

Catkin Workspace Preparation

```
$ source /opt/ros/$ROS_DISTRO/setup.bash
$ mkdir -p ~/camera_ws/src
$ cd ~/camera_ws/src
$ catkin_init_workspace
```

- **NOTE:** Replace `$ROS_DISTRO` to the ROS distribution of your system, `kinetic` or `melodic`.

ToF Camera ROS Driver Software Codes

Unzip "cis_camera.zip" in Ubuntu and put `cis_camera` folder in `~/camera_ws/src` .

- **NOTE:** Please DO NOT uncompress the ZIP file in MS Windows because file permissions are lost.

Build

```
$ cd ~/camera_ws
$ rosdep install -y -r --from-paths src --ignore-src
$ catkin_make
$ source ~/camera_ws/devel/setup.bash
```

Connecting Camera

1. Connect the camera to the USB 3.0 port of your Ubuntu PC
2. Connect the external power source to the camera and turn it on

Launching Software

PointCloud

To see the pointcloud with RViz,

```
$ source ~/camera_ws/devel/setup.bash
$ roslaunch cis_camera pointcloud.launch
```

NOTICE


At the first launch, you may get a device permission error like below.

```
$ roslaunch cis_camera pointcloud.launch
...

[ERROR] [1553240805.160155192]: Permission denied opening /dev/bus/usb/002/018
...
```

Change the permission of the port displayed in the error by the following method, and execute the launch file again. (The port number of the device is different every time, please replace it each time.)

```
$ sudo chmod o+w /dev/bus/usb/002/018
```



Publishing Images Only

When you publish only Depth, IR and RGB images, launch `tof.launch`.

```
$ source ~/camera_ws/devel/setup.bash
$ roslaunch cis_camera tof.launch
```


If you show the images, run `rqt` and open Plugins -> Visualization -> Image View.

```
$ source ~/camera_ws/devel/setup.bash
$ rqt
```

Dynamic Reconfigure

After you launched `pointcloud.launch` or `tof.launch` ,
you can reconfigure Depth/IR configurations dynamically with `rqt_reconfigure` .

```
$ source ~/camera_ws/devel/setup.bash
$ rosrn rqt_reconfigure rqt_reconfigure
```



Quit Software

Enter `ctrl-c` on the running terminal.